

**GB**

### **Application**

For priming all natural stone covering before grouting with NATURSTEINSILICON 630.

### **How-to-use**

Brush onto clean, dry joint flanks. Ventilate for 60 minutes. Apply silicone sealant within 4 hours.

**Usage:** Approx. 5 ml/m. **Shelf life:** In original packaging, use until: See label. Store cool. **Disposal:** Recycle empty packaging.

**Please take note of the details in the Harmful Substances Section and in the Technical Instructions Sheet.**